Deconstruction Rapid Assessment Tool



DISCLAIMER: This document is provided for information purposes only and may not be interpreted to alter or replace the coverage or requirements of any applicable regulations, policies or guidelines. If you are not clear what the legal requirements are for any aspect of a demolition, you should check before proceeding. Nothing contained in this document provides any defense in a state, local or EPA enforcement action, or creates any rights for or in any parties. While EPA has made every effort to ensure the accuracy of the discussion in this document, the obligations of the regulated community are determined by statutes, regulations or other legally binding requirements. In the event of a conflict between the discussion in this document and any statute or regulation, this document would not be controlling.



Introduction

- 1. What is Deconstruction?
- 2. Why Conduct Deconstruction Rapid Building Assessments?
- 3. How can the Deconstruction Rapid Assessment Tool Data be Used?
- 4. Will it Work for All Planned Residential Demolitions?
- 5. Can the Tool be Customized for Specific Applications?
- 6. What About Rehabilitation Candidates?
- 7. Are Specialized Skills or Training Needed?

1. What is Deconstruction?

Deconstruction is a way to systematically dismantle a structure to recover materials for reuse or recycling. Local governments or organizations with active demolition programs have an opportunity to promote environmental stewardship and economic revitalization through deconstruction. While it is possible to completely deconstruct a structure, there are frequently considerations of time, project budget, and material value that result in a more selective approach. In the case of a residential structure, deconstruction may recover materials such as architectural millwork, bricks, or even dimensional lumber. In addition to salvaging these potentially valuable materials, many deconstruction projects provide additional benefits pertaining to public health, waste diversion, job creation, and revenue generation.

2. Why Conduct Deconstruction Rapid Building Assessments?

Picking the best deconstruction candidates can be challenging. Oftentimes, choices must be made among a large quantity of eligible structures and in a short time period. Therefore, a quick scan of property qualities is necessary so that building removal programs can be better designed to recover as many materials as possible while working within funding constraints.

The Deconstruction Rapid Assessment Tool enables organizations to triage building stock slated for demolition by generating a dataset that can help prioritize structures for deconstruction and salvage. The assessment process identifies candidates for deconstruction by examining information on the building's condition and salvageable material

Benefits of Deconstruction

- · Blight management.
- Reduce public health and environmental impact.
- Workforce development and job training.
- Improved construction waste diversion.
- · Materials market development.

inventory. Whether the project scope is a few structures in a neighborhood, or an entire city's blight program, a rapid assessment can help managers make critical decisions regarding the allocation of resources and time.

3. How can the Deconstruction Rapid Assessment Tool Data be Used?


Data collected using the Deconstruction Rapid Assessment Tool can provide meaningful information so decision makers can pinpoint the preferred level of salvage operation. As stated above, the Deconstruction Rapid Assessment Tool helps identify structures most eligible for deconstruction and to inventory salvageable materials. Where deconstruction is viable, the Deconstruction Rapid Assessment Tool sheds light on the exact types and quantity of materials that can be recovered. The materials inventory enables program managers to assign a relative duration for deconstruction activities. For example, a deconstruction team may take a "skim" approach of one to two days, or up to 10 days for full deconstruction.

The variability in deconstruction time is dependent on the potential value of materials and the ease in which they can be recovered. However, these aspects of the deconstruction process can be qualitatively and quantitatively explored using the Deconstruction Rapid Assessment Tool. Some targeted materials are more viable to recover than others based on their market value and the level of effort needed to access, dismantle, transport, store, and bring them to market. Many materials need a certain level of expertise to remove and carefully transport, whereas some

On the Road to Reuse

In 2013, U.S. Environmental Protection Agency Region 5 produced the "On the Road to Reuse: Residential **Demolition Bid Specification** Development Tool" that identifies environmentally sensitive activities associated with demolishing residential buildings. These activities include hazardous materials abatement, fill material selection and placement, and material recycling. Environmental considerations are relevant throughout the entire demolition or deconstruction process, beginning with pre-planning and ending with site rehabilitation.

materials—particularly those targeted for recycling as opposed to reuse—have few restrictions for removal and handling. When considering these variables, a common challenge has been to effectively plan for and manage the deconstruction process, especially for large numbers of planned demolitions within a given city.



MATERIALS MARKET VALUE

Below are hypothetical situations to demonstrate how this scenario framework can inform the deconstruction decision-making process. Localized factors, both for access to materials and materials market value, will impact decisions made by each user.

- Access: Impassable entry, building collapse. Value: Little wood, no architectural features.
- Access: Roof collapse, excessive dumping. Value: Aluminum siding, metal roofing.
- Access: Significant exterior trash, bulky furniture. Value: Solid wood doors, wood-framed
- **Access:** Basement flooding, abandoned cars on site, not fully secured. **Value:** Claw foot tub, sinks, iron gate with fencing.
- **Access:** Limited interior trash, some graffiti. **Value:** Crown and baseboard moulding throughout house, other architectural work, fire place mantel.
- **F** Access: Some dumping and tires present on site. Value: Dimensional ceiling joists, large dimensional old growth lumber, built-in wood cabinetry, stained-glass windows.

The DRAT Action Framework above is intended to illustrate how access to materials and materials market value can influence decision-making for DRAT users.

Factors influencing access to materials may include:

- The age of the structure, which may indicate the presence of hazards such as lead paint.
- Lot conditions and other nuisances, which may determine ease of access or time required to ready site for deconstruction, such as the availability of a staging area or the presence of obstructions such as trash.
- Damage and deterioration, which may indicate the safety of working conditions, such as compromised structural integrity or fire damage.
- Environmental hazards, such as wasp nests or containers of chemicals, which may require extra precautions or steps for removal.

Data for access to materials will be populated in the first half of the tool under "Site Observations and Hazards."

Assessment of materials market value may be influenced by:

- The size of the structure or quantity of material.
- · Type and quality or condition of material.
- Salvage or recycling potential.

Data for market value will be populated in the second half of the tool under "Damage and Deterioration," "Materials Inventory," and "Special Consideration for Architectural Features."

Using information collected during the assessment, managers are able to assign a classification to the structure, broadly defined as follows:

- Demolition may be the best option for candidates with poor access to materials and low materials market value. Local factors, such as tipping, fees may incentivize demolition with recycling.
- Demolition with recycling* may occur when candidates exhibit better access to materials and higher materials market value than traditional demolitions, but materials are better suited for recycling than salvage.
- One to two day deconstruction may occur when candidates exhibit better materials access and higher materials
 market value than demolition with recycling, but the quantity of salvageable materials can be recovered in fewer
 than three days. Damage may be present, but isolated to specific rooms or sections.
- 3+ day deconstruction may be the best option for candidates with good access to materials and high materials market value. Local factors such as availability of program funds or time constraints may limit scope. The structure should be demolished, but contains opportunities for salvage or deconstruction of architectural finishes and fixtures and/or other materials. Damage may be present, but isolated to specific rooms or sections. The structure appears stable and safe to work in. The property is either currently secure or should be secured immediately.
- 5+ day (or full) deconstruction may be the best option for candidates with better access to materials and higher materials market value than 3+ day deconstruction and when program funds are sufficient to extend the time for project completion to allow for maximum material recovery.

*Materials recycling should be considered in all cases

Decision-makers should find it possible to determine candidates for demolition, demolition with recycling or for multi day deconstruction. Decision-makers may find it more difficult to determine the tipping point between one to two day and 3+ day deconstruction candidates. This task may be made simpler by using an internal weighting system, which can assign values to some of the data points in the tool based on local priorities and factors such as funding availability, project scale, or local materials markets.

4. Will it Work for All Planned Residential Demolitions?

The tool is applicable to cities and any other organization that has residential structures planned for demolition. Cities with large underutilized building inventories may use the tool to plan and manage the demolition process, whereas a state department of transportation or local hospital expanding into a residential community may use the tool as part of planned demolition activities to demonstrate environmental stewardship or build community support and alleviate environmental impact concerns.

Scenarios	Users	DRAT Potential Uses	Example
Blight Removal	Cities, Municipalities, Land Banks	 Assist program managers with making informed choices on the top prospects for building deconstruction. Create a more comprehensive understanding of blight issues through tracking, mapping, analysis, and linking addresses to structure conditions. Determine specific buildings to be bundled in each solicitation for contractors. 	Detroit Land Bank and Building Authority
Infrastructure Projects	Department of Transportation, Floodplain Management Districts, Sewer Districts	 Aggregate information about properties acquired as part of large infrastructure projects. Identify homes in good and habitable condition that may have a considerable amount of salvageable material. Assess the extent to which deconstruction may reduce project's environmental impact and provide job training. 	Cincinnati, Ohio Metropolitan Sewer District Lick Run Project Milwaukee, Wis. Metropolitan Sewer District Kinnickinnic River Project
Institutional Expansions	Hospitals, Universities, Anchor Institutions	 Plan and document how projects align with institutional goals, e.g., promoting health and community values. Act as an educational exercise for student planners and engineers evaluating large demolition/deconstruction projects. 	Detroit, Mich. Ford Hospital Expansion
Workforce Development	Demolition or Deconstruction Contractor, Job Training Programs	 Map landscape of demolition work to help organize demolition/deconstruction training opportunities. Assist deconstruction educators in identifying potentially salvageable and recyclable materials onsite and set expectations for trainees before beginning work. 	Cincinnati, Ohio Building Value Detroit, Mich. Reclaim Detroit

5. Can the Tool be Customized for Specific Applications?

It is expected that the tool may need to be tailored to specific needs based on local opportunities and constraints. The Excel version of the tool enables users to customize it by reducing, adding, or modifying data collection points to fit specific needs. Some users may develop an index by assigning a weight to each variable to calculate an index value or "score," which may aid in the prioritization and local decision-making process. Other users may pursue more integrated solutions by linking the tool to other property management databases or existing property assessments. Users are encouraged to adapt this general version based on local issues and materials market considerations.

6. What About Rehabilitation Candidates?

The Deconstruction Rapid Assessment Tool is aimed at inventorying structures that are already on a "Demolition List." Preserving existing housing stock is always preferable when structural and market conditions allow. After all, the greenest house is the one that already exists. In many cities, there is a separate evaluation for rehabilitation potential that takes place at an earlier stage. This earlier evaluation would determine the value for rehabilitation and evaluate the risks of associated investment.

However, the Tool can help to identify rehabilitation candidates that have mistakenly been added to the inventory of homes slated for demolition. Intervention could then prevent unnecessary demolition or deconstruction of a home that would otherwise hold its value in the market and help to stabilize neighborhood conditions.

7. Are Specialized Skills or Training Needed?

Completing the Deconstruction Rapid Assessment Tool only requires a basic understanding of construction and assessments can be completed fairly quickly. Data points include general information obtained through site observations, followed by more detailed notes on interior quality. It is important to remember that deconstruction does not have to be all or nothing. It is possible to engage in deconstruction activities at various scales that makes sense under specific site conditions and with available resources.



Instructions: Deconstruction Rapid Assessment Tool

Overview

As an alternative to traditional residential demolition, deconstruction is a way to selectively dismantle a structure to recover materials for reuse or recycling. In addition to diverting demolition wastes from landfills, deconstruction protects community health, creates deconstruction jobs, and stimulates the local materials market. The Deconstruction Rapid Assessment Tool provides meaningful information regarding structure condition and salvageable materials to help organizations identify the best candidates for residential deconstruction projects.

The instructions are intended to provide users with requisite information, including guidance on the assignment of values and terminology, to make the resulting product a useful tool for the organization.

- 1. Where Do I Begin?
- 2. What the Tool Includes
 - a. Site Observations & Hazards
 - b. Damage & Deterioration
 - c. Materials Inventory
 - d. Special Consideration for Architectural Features
- 3. Guidance for Selecting the Best Response
- 4. Why is Completing the Deconstruction Rapid Assessment Important?
- 5. Is Additional Documentation Needed?

1. Where Do I Begin?

The general information section of the tool should be populated prior to a site visit based on available data from public records. It includes fields such as the property address, property index number (PIN), year built, and other basic information. The address and PIN are of particular importance for tracking purposes to ensure that the collected data is matched to specific property records. If linked to existing databases, the majority of this information could be automatically generated based on the PIN.

2. What the Tool Includes

2a. Site Observations & Hazards

The Deconstruction Rapid Assessment Tool addresses site observations and hazards prior to building characteristics. Site observations will be variable from site to site and between neighborhoods and are of general concern to the community. Depending on what is observed on site, preparation activities may differ. For example, if there are hazards that need to be mitigated – such as the presence of dogs – prior to safely deconstructing the home, this information will help bring such considerations to the attention of program management. The presence of trash, particularly if it is inside, is very important to note as it may lead to more costly deconstruction projects.

The majority of the Site Observation section can be completed outside of the home with a basic walkaround to visually assess the entire site. There are cases when this information may be used for code enforcement purposes in an effort to stabilize the community prior to demolition.

Structures built pre-1978 are likely to contain lead-based paint and asbestos products. Lead and asbestos are not addressed in the Deconstruction Rapid Assessment Tool because most individuals are unable to readily affirm their presence, and these considerations should be built into the process separately for inspection by a trained environmental professional.

		SITE OBSI	RVATIONS &	HAZARDS		
Is the structure currently secured to prevent unwanted entry?		Fully	Partly	No		
Is there room around the structure to serve as staging area?		Yes	No			
Presence of exterior trash?		No Trash	Limited Trash (Scattered Debris)	Significant Trash (Piles of Trash)	Appliances/	Impassable/ Entry Restricted
Presence of interior trash?		No Trash	Limited Trash	Significant Trash (Piles of Trash)	Large Appliances/ Bulky	Impassable/ Entry Restricted
Were any of the following observed onsite?		Tires	Abandoned cars	Graffiti	Signs of Drug-Use	Containers of Chemicals / Oil
	If observed, how many tires are present?					
Were hazards present on-site?		Dogs	Bees/Wasps	Excessive Dumping	Excessive Mold	
Is structural evaluation recommended? (Collapse, partial collapse, or building off foundation)		Yes	No			

2b. Damage & Deterioration

The Damage & Deterioration section is intended to provide an indication of the condition of materials in the structure. If, for example, there are large portions of the roof missing and clear exposure to the elements or missing windows, the chances of materials being damaged and/or deteriorated is increased, thereby making deconstruction unlikely. This is very important in understanding whether deconstruction will be a viable option. For projects in which the structure was recently occupied and in habitable condition, this section may have diminished relevance.

	DAMAG	SE 8	& DETERIO	RA	ATION				
Major cracking of brick, wood rotting:			Yes		No				
Broken or missing windows:						Yes		No	
Missing brick and siding:			Yes		No				
Roof damage:	Small Large				Portion of	Significant portion or			
Roof dafflage.	open hole open hole(s)				oof missing	entire	entire roof missing		
Evidence of major fire damage:	1 (little)		2		3	4		5 (lots)	
Evidence of major water damage:	1 (little)		2		3	4		5 (lots)	
Are gutters/downspout operable to contr			Yes		No				

2c. Materials Inventory

The materials inventory includes the types and quantities of building elements commonly found in residential structures. This information is intended to provide estimates of effort required to deconstruct and potential revenue from deconstructed materials.

		MA	TERL	ALS INVEN	TORY		
Roof type:		Fla	at	Pitched			
Siding type:	Brick	1 (little)	2	3	4	5 (lots)
	Wood	1 (little)	2	3	4	5 (lots)
	Stone	1 (little)	2	3	4	5 (lots)
	Vinyl/Synthetic	1 (little)	2	3	4	5 (lots)
	Aluminum	1 (little)	2	3	4	5 (lots)
	Other:	1 (little)	2	3	4	5 (lots)
Wood floorin	g (number of rooms) :		1	2	3	4	Specify:
	nal layers of flooring been e wood in the past?	Ye	es	No			
observed?	nal ceiling or floor joists	Ye	es	No			
•	ed from basement or attic)						
	umber larger than 4x4:	Ye	25	No			
	ter or drywall?	Plaster		Partly			
(total should	equal 100%)			(< 25%)	(25-50%)	` .	(100%)
		Drywall		Partly (< 25%)	Some (25-50%)	,	(100%)
	Crown moulding	Nor	ie	Some	A Lot		
	Casing around doors and windows (number of rooms)		1	2	3	4	Specify:
	Baseboard moulding (number of rooms)		1	2	3	4	Specify:
	Chair railing moulding (number of rooms)		1	2	3	4	Specify:
Foundation:		Monolith concret		Concrete block	Combination	, specify:	
	Basement:						

2d. Special Consideration for Architectural Features

This section itemizes some of the more valuable items that should be noted when found. Both unique and standard building materials can be safely removed, resold, and ultimately used in another building. The presence of a few special items can oftentimes mean the difference between a traditional demolition and a one- or two-day deconstruction project that "skims" easily accessible items. In some cases, a real "gem" is found when the house is filled with valuable features, which may merit additional deconstruction effort. Similarly, a house slated for removal due to a future infrastructure project may be in good condition and provide a wealth of salvageable items. Tallying up the materials inside a home also provides future deconstruction contractors with a heads-up in case they need to locate a buyer for a particularly rare item.

		SPECIAL C	ONSIDERATI	ON FOR ARCH	ITECTURAL FI	EATURES			
Interior:		place mantel nt and intact?	Yes		Decorative	architectural wrought iron		Yes	
	Stair t	reads/railings	Yes		Lig	ghting fixtures		Yes	
	Other woodwork (d	architectural cornices, etc.)	Yes		Radiators			Yes	
	Interior stone details (counter, fireplace) Stained / leaded glass		Yes			Registers		Yes	
			Yes		Sinks			Yes	
	Solie	Solid wood doors Yes Claw foot tub			Yes				
	Door hardware		Yes			1st floor		2nd floor	
	Wood fran	med windows	Yes			liances (oven, igerator, etc.)		Yes	
	Built-in wo	ood cabinetry	Yes			Countertops		Yes	
Exterior:	(cornersto	stone details nes, window Ikways, etc.)	Yes						
		ates/fencing	Yes						
	N	∕letal roofing	Yes						

3. Guidance for Selecting the Best Response

Respondents are able to use rough estimates and descriptions to identify how the structure compares to a continuum of options. Some questions have numerical scales or percentage-based options. For questions on a numerical scale of 5, consider 1 to be less than 20 percent, 3 to be roughly half, and 5 to be over 80 percent. Empirical measurements are not necessary. When using the tool, it is good to err on the side of caution. For example, if asked to estimate a response on a scale of 1 to 5, and the user believes the response should be 2.5, use 2 as the response. The rationale of using a scale is to allow users to do quick visual survey and record estimates.

4. Why is Completing the Deconstruction Rapid Assessment Important?

Structures slated to be demolished represent a broad continuum of condition and opportunity for deconstruction or rehabilitation. Upon completion, a recommendation for deconstruction, demolition, or an additional rehabilitation assessment will be made by a central management team based on data collected and reported from the tool. This recommendation can be used for planning and management of the demolition process in cities.

5. Is Additional Documentation Needed?

It is always a good idea to have tool users photo-document each structure by taking both interior and exterior pictures during the evaluation. If the form is completed digitally or through an independently developed app, it may be possible to automatically link the images in a database. Such documentation will enable a more informed decision to be made regarding structure rehabilitation, deconstruction, or demolition.

